

Agilent 6000 Oscilloscope Screen Capture – Revised March 4, 2008

- 1. Turn Oscilloscope power OFF.**
- 2. Logon to Windows, and before loading any other programs, turn Oscilloscope power ON.**
- 3. “Assign USB Device Alias” text box displays – click “OK”.**
- 4. Start Microsoft Word – Agilent 6000 toolbar will display.**

If Agilent 6000 Toolbar is not displayed:

Click “View” “Toolbars” then Click “Agilent 6000 Toolbar”

If “Agilent 6000 Toolbar” is not in “Toolbar” list:

On the Tools menu, click “Templates and Add-Ins”.

Click “Attach”.

Look In: “Local Disk C:”.

Double Click “Program Files | Agilent | Intuilink | 6000 Toolbar | agt6000.dot”.

Click “OK” – text box displays: “This application...ActiveX...”

Click “OK” – Agilent 6000 Toolbar will appear.

- 5. Click “Connect to Scope” icon on toolbar – “Searching Busses” displays momentarily.**
- 6. “Find Instrument” text box displays.**
- 7. Double-click on “USB0:....” then click OK.**
- 8. Click on Camera icon – “Get Screen Image” text box displays. Click OK. The screen image will appear in document in about 12 seconds.**

Note: You can save this file for future screen captures and the toolbar should display automatically.